

# ADVANCED REACTORS AND THE NEED FOR ADVANCED CONTROL SYSTEMS, JULY 12-14, 2023, LEMONT, IL



## DIGITAL TWINS FOR HEALTH MONITORING TO SUPPORT ADVANCED CONTROL



**TIM NGUYEN**  
Argonne National Laboratory

July 12, 2023


This work was supported by the U.S. Department of Energy, Office of Nuclear Energy. The submitted manuscript was created by UChicago Argonne, LLC, operator of Argonne National Laboratory. Argonne, a DOE Office of Science laboratory, is operated under contract DE-AC02-06CH11357. The U.S. Government retains for itself, and others acting on its behalf, a paid-up nonexclusive, irrevocable worldwide license in said article to reproduce, prepare derivative works, distribute copies to the public, and perform publicly and display publicly, by or on behalf of the Government. The DOE will provide public access to these results of federally sponsored research in accordance with the DOE Public Access Plan at <http://energy.gov/downloads/doe-public-access-plan>.

# OUTLINE

- Overview
- Digital Twins for Fault Diagnostics
- Examples
- Conclusion

# OVERVIEW


- Diagnostics is an integral part of advanced control:
  - Equipment health for O&M decision
  - Instrument health for control
- Desired capabilities:
  - Differentiate component and sensor faults
  - Provide explainable diagnoses to operator



Structure of a proposed autonomous control system architecture (Ponciroli et al.)


# DIGITAL TWINS FOR DIAGNOSTICS

- Utilized in model-based diagnosis:
  - Enable detection and diagnosis of component and sensor faults
  - Allow robust treatment of uncertainty in reasoning process
- Facilitate explainable diagnosis:
  - Clear cause-effect relations between faults and symptoms



# IMPLEMENTATION IN PRO-AID



- Under development at Argonne
  - Featured in a live demo on 7/14
- Prioritized capabilities:
  - Detection of equipment and sensor faults
  - Robust uncertainty treatment
  - Explainable, actionable diagnoses
  - No design parameters, configurable to generic systems



# EXAMPLE 1: MONTICELLO BWR FEED PUMPS

## Results






- Diagnostic results:
  - Symptoms: Non-zero residuals for RFP 1
  - Diagnosis: Pump fault in RFP 1
- Confirmed by Xcel:
  - Flow straightener failure in RFP 1 at approx. 15:00 on day 474



DIAGNOSTIC RESULT		
Reasoning method: Probabilistic		
Faults, ranked by posterior probability:		
Rank	Fault Name	Probability
1	Pump-rfp11	0.73359
2	SensorFault-rfp11:vflow:in	0.16370
3	Bearings-rfp11	0.14803
4	SensorFault-rfp11:press:in	0.13371
5	SensorFault-rfp11:press:out	0.13371
6	Motor-rfp11	0.07776
7	SensorFault-rfp11:power:mid	0.00149
8	SensorFault-rfp11:current:mid	0.00023
9	SensorFault-rfp11:rspeed:mid	0.00004

# EXAMPLE 2: THERMAL STORAGE SYSTEM

- Fault scenario:
  - HT-V2 valve stuck
  - IHX Fouling



# CONCLUSION

- Essential role of diagnostics in advanced control:
  - Detection of sensor faults to ensure proper control
  - Monitor equipment health to support O&M decision
- Benefits of digital-twin-based approach:
  - Utilize physics-based diagnosis information to supplement sensor data
  - Enable detecting and differentiating both component and sensor faults
  - Facilitate explainable diagnoses



# THANK YOU



Argonne National Laboratory is a  
U.S. Department of Energy laboratory  
managed by UChicago Argonne, LLC.

